

LEVEL

LEA 076..

LEA 077..

LEA 078..

LEA 876..

LEA 877..

LEA 878..

LEA 136..


LEA 137..

LEA 138..

LEA 836..


LEA 837..

LEA 838..



1


Montaggio Assembly




$65 \pm 5^{\circ}\text{C}$



$15 \pm 5^{\circ}\text{C}$




MIN - MAX



OK


2 a

078
878
138
838





b

 CALDO
HOT






 FREDDO
COLD




3

876
877
076
077
136
137
836
837




G 3/8"




076
077
078
876
877
878
136
137
138
836
837
838

4 a




b




876
877
076
077
136
137
836
837

c




M

Manutenzione
Service



Sa


Sostituzione Cartuccia e canna How to replace Cartridge and spout



076
077
078
876
877
878
136
137
138
836
837
838

b

Sostituzione Snodo How to replace Joint



136
137
138



Sostituzione Aeratore How to replace Aerator

876

877

878

836


837

c


076

077

078



d



Sostituzione Canna How to replace Spout

e

